




# Crank 6243.4L (left) for Sense 62033 and 62034 basin, installation instructions.








## 6243.4L





(Basin is not included in package.)






6243.4L



# A5



# B1




> [korpinen.com](https://www.korpinen.com)

[https://www.korpinen.com/uploads/documents/Gaius\\_water\\_trap-2018.pdf](https://www.korpinen.com/uploads/documents/Gaius_water_trap-2018.pdf)


# Crank 6243.4R

measures, water and drain places.


Body frame measures  
and  
reinforce area




Water and  
drain places



Water and  
drain pipes





# A



## A1




Reinforce area  
36mm or more plywood  
or  
45mm or more solid wood








# A2




# A3




# A4




## A.





## B.




## C.




# B2




# C1




A.




# C2



B.



C.



D.

