

CARE INSTRUCTIONS

RST-LINE PRODUCTS

RST-Line liquid soap dispenser

Lift the dispenser upwards to dismount it from the wall rack. Empty the dispenser and clean the inside approximately twice a year. Thoroughly rinse the inside of the dispenser with warm water and pump warm water through, until the water is clear. This prevents the pump from becoming blocked and extends the dispenser's service life. If soap dispensers are not continuously in use (e.g. during school holidays), it is recommended to empty and clean them for the break.



RST-Line paper towel dispenser

To open the paper towel dispenser, lift the lid vertically and tilt forwards. When adding paper towels, remove the plastic wrapping and 'vent' the papers. This is to ensure that the towels are dispensed one at a time. Place the folded edge at the front, so that the paper will not tear easily when pulled. A too compact pile of towels will cause tearing, or several towels are dispensed at the same time.



RST-Line dustbin

The dustbin comes with a garbage bag frame. It helps to place the bag neatly inside the bin, so that it does not hang out.



RST-Line toilet paper dispenser

We recommend that the rolls are placed so that the paper unrolls from the back wall side. Release the glued ends of the rolls. Inside the dispenser, there is a small lip that can be bent to allow the use of toilet rolls that are smaller than normal. Lift the lip upwards, so that the rolls remain above it and the bottom one can roll freely. When the bottom roll runs out, remove it through the bottom of the dispenser and release a new roll by pressing in the middle.



Cleaning instructions for RST-products

Stainless steel is a porous material, and microbes can survive on its surface for a long time. The steel surfaces of Korpinen products are coated with antimicrobial lacquer. The antimicrobial lacquer makes the products easier to clean and reduces the spreading of infections via surfaces. Use neutral or slightly alkaline (pH 7 – max. 10.5) all-purpose cleaner for maintenance cleaning. Avoid abrasive agents. The cleaning product must not form layers on the surface of an antimicrobial product. Therefore, it is important to choose the correct cleaning products and follow the dosage instructions.