

CARE INSTRUCTIONS



CAST MARBLE BASINS

The Gaius basins are made of antimicrobial cast marble.

Cleaning: Remove any discharge immediately with a disinfectant cleaner. The disinfecting agent kills microbes and prevents their growth. These cleaners contain surfactants, a disinfecting agent and alkalis or acids. They may be hydrogen peroxide-based.

Daily cleaning is the best way to avoid persistent stains and discolouration. Use neutral or slightly alkaline (pH 7 – max. 10.5) all-purpose cleaner for maintenance cleaning. The cleaning product must not form layers on the surface of an antimicrobial product. Therefore, it is important to choose the correct cleaning products and follow the dosage instructions. Do not use abrasive cleaning products or equipment. Microfibre cloths are recommended because of their efficient mechanics.

Do not pour boiling water or place very hot objects on the surface of the product. The highest temperature allowed is 80°C (the normal maximum temperature of tap water is about 60°C).

For more information, please visit www.korpinen.com

